

# How to use the SIM card

## iOS

1. Connect to the internet with Wi-Fi and scan the QR code.

Or Enter this URL with Safari :

<https://his-mobile.com/support/setting/dm-profile/>



2. Download the configuration profile and install.

Please continue to install when prompted.

3. Tap the settings icon on the Home screen.

Select [Mobile Data] and turn on [Enable 4G] or [Enable LTE].

## Notice

1. While you download the Network driver on your phone but can't access the link, Please use another browser to install.
2. Please delete the installed Network driver after using SIM: settings→general → profiles → delete the Network driver of H.I.S
3. Insert your own sim card and restart your mobile phone and then use as usual.

# How to use the SIM card

## Android

1. Select [Settings ]on the main menu
2. Select [Wireless & Networks]
3. Select [Mobile networks]
4. Select [Access Point Names]
5. Make a New APN Enter the APN, and authentication type provided below
6. Select [Save] from the menu, then return to the APN list and select the APN that you set up.

Name: his

APN: dm.jplat.net

User name: his@his

Password: his

Authentication type: PAP or CHAP

### Notice

1. While you download the Network driver on your phone but can't access the link, Please use another browser to install.
2. Please delete the installed Network driver after using: delete the APN of H.I.S
3. Insert your own sim card and restart your mobile phone and then use as usual.